



ESD Floor Cleaner

1 PRODUCT DESCRIPTION

Cleaning concentrate for the day-to-day cleaning and post-installation cleaning of conductive floors, also after sealing with Dr. Schutz ESD Sealers. Excellent dirt-binding properties, even with greasy residues. Does not leach out the surface, does not form grey haze. Cleaning without stripes.

2 AREAS OF APPLICATION

Conductive floors, which can deflect electrical charge.

3 APPLICATION

Remove coarse dirt by sweeping or vacuuming. Mop the floor with ESD Floor Cleaner diluted in a ratio of 1:200 in water free of stripes, removing abrasive marks and stains. For a stronger cleaning effect it is possible to use a higher concentration and/or a monodisc machine with a red pad. Take up the dirty solution with a mop, then mop the floor again to ensure it is free of stripes. For application with a cleaning machine the dilution can be increased to a ratio of 1:400 (25 ml in 10 litres water).

4 CONSUMPTION

Guideline: 0.1 litre on 100 m², but more in the case of heavy soiling

7 STORAGE

Protect against frost. Store in a cool, dry place. Will keep for 24 months in unopened, original canister from the date of manufacture. Keep coating materials out of the reach of children.

8 TECHNICAL DATA

Contains substances: less than 5% anionic surfactants, 5-15% non-anionic surfactants, fragrances, LIMONENE, solvents.

pH: 8,5

ADR/RID: not a dangerous good as defined by transport regulations.

CLP: GHS07, Warning. H319 Causes serious eye irritation. P101 If medical advice is needed, have product container or label at hand. P102 Keep out of reach of children. P280 Wear eye protection / face protection.

P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P337+P313 If eye irritation persists: Get medical advice/attention. P501 Dispose of contents/container in accordance with local/regional/national/international regulations.



ESD Floor Cleaner

9 SPECIAL NOTES

10 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage www.dr-schutz.com or on request from the address quoted below.

Dr. Schutz – We Care About Floors

Headquarter
CC-Dr. Schutz GmbH
Holbeinstraße 17
D-53175 Bonn
Tel.: + 49 228 / 95 35 2-40
Fax: + 49 228 / 95 35 2-46
E-Mail: export@dr-schutz.com
www.dr-schutz.com

UK
Dr. Schutz U.K Ltd.
Unit 24, Anglo Business Park,
Smeaton Close, Aylesbury Bucks
HP19 8UP

Contact: Richard Nelson
Tel.: 0044 / 1296 437827
Fax: 0044 / 1296 334219
E-Mail: richard@dr-schutz.com

Ireland
Dr. Schutz Ireland
35 Pic Du Jer Park,
Ballinlough, Cork

Contact: Paul O'Reardon
Mobile: 0877678388
E-Mail: drschutzireland@gmail.com

North America
Schutz NA
4701 Bath St 46, Philadelphia
PA 19137, USA

Contact: Sam Jamison
Tel.: 001 / 877 272 4889
Mobile: 001 / 215 510 7874
E-Mail: sam@schutzNA.com

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.